

# **ONIGOE-mini**

## Manual

Ver. 1.1

\*The specification and manual of this product can be change without notice.


#### 1. Precaution

- Power source
   Please use AA battery.
- Handling
   Do not drop, shock or vibrate the device.

   It may damage device.
- Dismantling
   Do not dismantle the product. We will not be responsible on damage caused by dismantling the product.

#### 2. Content of the box

O Control box




O Touch switch button • • • • • 2



O Cable (2.5m) • • • • • • 2

# 3. Preparation (Connecting the parts)



Please connect as shown in the figure above. Each plug Please insert to the last jack.

#### 4. How to use

- Switch on
- All indicator lights will turn-on, touch 1 of the touch switch button to begin.
   Training begin after 3 sec.
- Display -AVERAGE TIME
- Restart touch 1 of the touch switch button to begin Training.

### 5. Specification

Power source4 AA size battery

Dimension

Control box 170X85X60mm
Touch switch button 93X93X92mm

Weight

Control box 290g
Touch switch button 85g